



Installing WaterUps® in Intermediate Bulk Containers (IBCs)

WaterUps® Wicking Cells can easily be added to Intermediate Bulk Containers (IBCs) to create an efficient wicking system.



QUICK TIP

As IBCs are used as a storage/transport device for a range of liquids, you should check what the IBC has been used for and if possible secure a food grade IBC.

Cutting the IBC into 2 halves

In order to cut your IBC into 2 halves you will need to:

1. Remove the metal cage. To do this you will need to firstly remove the top bars using a T30 head bit.
2. Remove the metal frame and place the plastic tank upright (so that the screw top is at the top) on a flat surface.
3. Measure and mark a line around the plastic tank at the vertical halfway point.

4. Now lay your IBC on its side.
5. Cut your IBC in half. This will give you a depth of approx 500mm. Given that efficient wicking will occur up to a height of around 350mm, you can adjust your soil depth (from the base of your WaterUps® wicking cell) based on what you are planting. Remember you will need to allow for 50mm of mulch and the sand in to base. For example, if you are intending planting deeper rooting plants, such as a lemon tree, then you could use the full depth of your IBC.

Cutting the IBC frame

You will now need to cut the metal frame of your IBC in half for the inserts, that you have cut, to sit in.

Note: You will need an angle grinder to do this.



Positioning the WaterUps® cells

Your IBC will be approximately 1000mm x 1200mm. Therefore, you will need 9 WaterUps® Cells. The cell configuration will be 3 cells down each side of the 1200mm section and then 3 half cells down the middle.

It is important that you have a level base for your IBC to sit on. We suggest that you use a spirit level to check. Given that the floor of your IBC will not be completely even, add a layer of coarse sand to the floor of your IBC so that the WaterUps® cells have an even base to sit on. You will need about 4 buckets of sand or gravel.

On top of the sand, it is recommended that you add a layer of GeoTec fabric or corflute sheet to ensure that the WaterUps® cell base remains even and stable over time.

Cutting the cells

Firstly you will need to cut a diagonal off 1 corner of 4 WaterUps® cells, so that they fit snugly into the round corners of the IBC.

After positioning the 4 corner cells and the middle cells along the 1200mm sides, measure the gap in the centre – this should be slightly less than 200mm. You will need to cut 2 cells so that you are left with 3 pieces of that width, so that the cell base fits closely to the edges and evenly in the centre. This can be easily done with a handsaw or a jigsaw.

Drilling the overflow hole

To locate the precise position for the overflow hole:

- Check the underside of the WaterUps® cell for the semi circle that has been moulded to fit the overflow pipe and attached to the pipe with cable ties;
- Now place the cell on top of the GeoTec/Corflute sheet that covers the level sand/gravel base of the IBC so that the overflow pipe touches the side wall;



- Trace the outline of the pipe, and mark the centre; and
- Finally, use the 20mm hole saw to drill the hole for the overflow pipe.

Covering the gap around the cells

Given that the internal width of the IBC will probably not fit the WaterUps® cell exactly, you will need to cover any small gaps to prevent soil from penetrating the water reservoir. This can be easily done by running a piece of GeoTec fabric around the inside perimeter, overlapping the top of the cells. A strip about 300mm wide would be ideal. You can secure the GeoTec to the walls of the container using Duct tape.

Adding inlet and overflow pipes

Now add the rest of the cells including the one for the inlet pipe. On that cell cut out the circle for the inlet pipe and insert it by aligning the 3 lugs at the base of the pipe with the holes in the cell.


Final steps

Now fill the 4 wicks of each cell with perlite and then add your potting mix, compost and plants.

Further Information

[Click here to view & download the WaterUps® Installation Guide](#)

Published: 17 September 2020



W www.waterups.com.au
P 1300 205 550
E sales@waterups.com.au



The WaterUps® website is owned and operated by WaterWix Pty Ltd – ABN 58 166 973 011. The information contained in this document is provided as is and without any warranties of any kind, whether expressed or implied. Users are advised to make their own determination as to the suitability of this information in relation to their particular purpose or specific circumstances. No responsibility can be accepted by WaterUps®, WaterWix Pty Ltd, or its staff for any loss resulting from any action taken or reliance made by you on any information contained in this document. Copyright © 2020 WaterWix Pty Ltd. All rights reserved. WaterUps and the WaterUps Logo are registered trademarks of WaterWix Pty Ltd

Save Water... Save Time... Grow healthier plants